



NOTE:  
 CORROSION COUPON RACK MUST BE LOCATED BELOW WATER LINE IN COOLING TOWER BASIN SO THAT IS FLOODED AT ALL TIMES.

INSTALL CORROSION COUPON RACK AT OPERATING LEVEL AWAY FROM ANY ELECTRICAL EQUIPMENT.

ENSURE DRAIN VALVES ARE INSTALLED IN ALL SYSTEM LOW POINTS.

Installation of Corrosion Coupon Rack, Chemical Metering System, & Total Dissolved Solids Control System for Evaporative Condenser Water System	2012 - 09 - 20
	Detail 23 25 01 05